

LIFESAVER LIBERTY GENERAL MAINTENANCE GUIDE

- In addition to maintaining the pump (see user guide) the main seal of the Liberty bottle requires some maintenance for best operation during periods of extreme usage and after long term storage.
- Remove the pump and run your finger around the base of the cartridge as pictured to check for abrasions or rough edges. Make sure the base is free of all debris and clean as required. Hardness salts can produce a build-up here and this will cause a loss of integrity between the base and outer shell. So it is important they are completely removed.
- To ensure the main cartridge seal is fully functioning and reliable it is recommended to use a small amount of (food grade) silicone grease to help seating. This will not wash away like other types of grease and is therefore best suited for the job.

- Take a small amount of grease on the end of your finger and wipe around the flat base of the bottom of the outer shell.



- Then put a further light smear of grease on your finger and wipe around the internal thread within the base pump as pictured in a circular direction.



- Assemble the pump back into the filter and tighten then disassemble visually inspect and remove any excess grease.
- Test your Liberty bottle by filling with water and pressurising. Your liberty bottle should now be ready for use again.